











平車規格件表 / CONVERSION CHART

P1

MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE
機 型	規 格	針 座	針 板	主 送 具	差 送 具	押 具	勾 針	上 叉	針 號
F007J-W121 F858J /UTG(UTJ)	240 248 356 364	M5240 M5248 M5356 M5364	E1514 E1515 E1816 E1817	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544-A P2545-A P2446-A P2447-A	ME28	MH41	UYX128GAS #10
F007J-U121 F858J	240 248 356 364	M5240 M5248 M5356 M5364	E1514 E1515 E1816 E1817	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544-A P2545-A P2446-A P2447-A	ME28	—	UYX128GAS #10
F007J-U121 F858J /UTH(UTK)	240 248 356 364	M5240 M5248 M5356 M5364	E1514 E1515 E1816 E1817	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544-A P2545-A P2446-A P2447-A	ME28	—	UYX128GAS #10
F007J-W122 F858J	240 248 356 364	M5240 M5248 M5356 M5364	E1524 E1525 E1826 E1827	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544-A P2545-A P2446-A P2447-A	ME28	MH41	UYX128GAS #10
F007J-U122 F858J	240 248 356 364	M5240 M5248 M5356 M5364	E1524 E1525 E1826 E1827	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544-A P2545-A P2446-A P2447-A	ME28	—	UYX128GAS #10
F007J-U122 F858J /UTH(UTK)	240 248 356 364	M5240 M5248 M5356 M5364	E1524 E1525 E1826 E1827	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544-A P2545-A P2446-A P2447-A	ME28	—	UYX128GAS #10











註：P2544-A/P2545-A為固定式押具舌，亦可使用活動式押具舌 P2565-A代替 P2544-A/P2545-A  
 P2544-A/P2545-A is the fixed presser foot tongue. It can be replaced by the removable presser foot tongue P2565-A.  
 P2446-A/P2447-A為固定式押具舌，亦可使用活動式押具舌 P2466-A代替 P2446-A/P2447-A  
 P2446-A/P2447-A is the fixed presser tongue. It can be replaced by the removable presser foot tongue P2466-A.

平車規格件表 / CONVERSION CHART

MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE
									
F007J-U122 F858J/FP	232	M5232	E1623	D1206	H1257	P4011-A	ME28P	—	TVX5 #14
F007J-W123 F858J	240 248 356 364	M5240 M5248 M5356 M5364	E1534 E1535 E1836 E1837	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544-A P2545-A P2446-A P2447-A	ME28	MH41	UYX128GAS #10
F007J-W123 F858J	240 248 356 364	M5240 M5248 M5356 M5364	E1534 E1535 E1836 E1837	D1206 D1206 D1207 D1207	H1258 H1258 H1259 H1259	P2544-A P2545-A P2446-A P2447-A	ME28	MH41	UYX128GAS #10
F007J-W162 F858J	356 364	M5356 M5364	E1846 E1847	D1207 D1207	H1259 H1259	P2446-A P2447-A	ME28A	MH41	TVX5 #14~16
F007J-U162 F858J	356 364	M5356 M5364	E1846 E1847	D1207 D1207	H1259 H1259	P2446-A P2447-A	ME28A	—	TVX5 #14~16
F007J-W162 F858J UTG(UTJ)	356 364	M5356 M5364	E1846 E1847	D1207 D1207	H1259 H1259	P2446-A P2447-A	ME28A	MH41	TVX5 #14~16
F007J-U162 F858J /UJH(UJK)	356 364	M5356 M5364	E1846 E1847	D1207 D1207	H1259 H1259	P2446-A P2447-A	ME28A	—	TVX5 #14~16
F007J-W222 F858J /FQ	232 240 248 356 364	M5232 M5240 M5248 M5356 M5364	E3023 E3024 E3025 E3326 E3327	D1215 D1215 D1215 D1216 D1216	H1261 H1261 H1261 H1262 H1262	P1813-A P1814-A P1815-A P2116-A P2117-A	ME28	MH41	UYX128GAS #10
F007J-W222 F858J /UTG(UTJ)/FQ	240 248 356 364	M5240 M5248 M5356 M5364	E3024 E3025 E3326 E3327	D1215 D1215 D1216 D1216	H1261 H1261 H1262 H1262	P1814-A P1815-A P2116-A P2117-A	ME28	MH41	UYX128GAS #10
F007J-U222 F858J /UJH(UJK)/FQ	240 248 356 364	M5240 M5248 M5356 M5364	E3024 E3025 E3326 E3327	D1215 D1215 D1216 D1216	H1261 H1261 H1262 H1262	P1814-A P1815-A P2116-A P2117-A	ME28	MH41	UYX128GAS #10

註：P2544-A/P2545-A為固定式押具舌，亦可使用活式押具舌 P2565-A代替P2544-A/P2545-A  
 P2544-A/P2545-A is the fixed presser foot tongue. It can be replaced by the removable presser foot tongue P2565-A.  
 P2446-A/P2447-A為固定式押具舌，亦可使用活式押具舌 P2466-A代替P2446-A/P2447-A  
 P2446-A/P2447-A is the fixed presser tongue. It can be replaced by the removable presser foot tongue P2466-A.

平車規格件表/CONVERSION CHART

									
MODEL	SUB-CLASS	NEEDLE CLAMP	NEEDLE PLATE	MAIN FEED DOG	DIFF. FEED DOG	PRESSER FOOT	LOOPER	SPREADER	NEEDLE
機 型	規 格	針 座	針 板	主 送 具	差 送 具	押 具	勾 針	上 叉	針 號
F007J-W222 F858J /FQ/FEC(FAC)	240 248 356 364	M5240 M5248 M5356 M5364	E 3024 E 3025 E 3326 E 3327	D1215 D1215 D1216 D1216	H1261 H1261 H1262 H1262	P2314-A P1815-A P2116-A P2117-A	ME28	MH41	UYX128GAS #10
F007J-U222 F858J /FQ	240 248 356 364	M5240 M5248 M5356 M5364	E 3024 E 3025 E 3326 E 3327	D1215 D1215 D1216 D1216	H1261 H1261 H1262 H1262	P2314-A P2315-A P2616-A P2617-A	ME28	—	UYX128GAS #10
F007J-W222A F858J FQ/FEC(FAC)	240 248 356 364	M5240 M5248 M5356 M5364	E 3124 E 3125 E 3426 E 3427	D1315 D1315 D1316 D1316	H1261 H1261 H1262 H1262	P1914-A P1915-A P2216-A P2217-A	ME28	MH41	UYX128GAS #10
F007J-U222 F858J /FFD(FFP)	240 248 356 364	M5240 M5248 M5356 M5364	E 3024 E 3025 E 3326 E 3327	D1215 D1215 D1216 D1216	H1261 H1261 H1262 H1262	P1814-A P1815-A P2116-A P2117-A	ME28	MH41	UYX128GAS #10
F007J-U222 F858J /FFD(FFP)	240 248 356 364	M5240 M5248 M5356 M5364	E 3024 E 3025 E 3326 E 3327	D1215 D1215 D1216 D1216	H1261 H1261 H1262 H1262	P2314-A P2315-A P2616-A P2617-A	ME28	—	UYX128GAS #10
F007J-W222 F858J /FSM	240-4 248-4 364-4	M5240P M5248P M5364P	E 3124 E 3125 E 3127	D1207 D1516	H1262 H1262 H1262	P2714-A P2715-A P2717-A	ME28	MH41	UYX128GAS #10
F007J-W322 F858J /FDC	356 364	M5356 M5364	E 4826 E 4827	D1207 D1207	H1359 H1359	P2446-A P2447-A	ME28	MH41	UYX128GAS #10
F007J-U322 F858J /FDC	356 364	M5356 M5364	E 4826 E 4827	D1207 D1207	H1359 H1359	P2446-A P2447-A	ME28	—	UYX128GAS #10

註：P2544-A/P2545-A為固定式押具舌，亦可使用活動式押具舌 P2565-A代替 P2544-A/P2545-A

P2544-A/P2545-A is the fixed presser foot tongue. It can be replaced by the removable presser foot tongue P2565-A.

P2446-A/P2447-A為固定式押具舌，亦可使用活動式押具舌 P2466-A代替 P2446-A/P2447-A

P2446-A/P2447-A is the fixed presser tongue. It can be replaced by the removable presser foot tongue P2466-A.

W222A-FAC(FEC) 短切刀 Short Trimmer

W222-FAC(FEC) 長切刀 Long Trimmer







































































